



Box contents

Shelf parts A, A1, B and B1
6x 4x40 screws
5x 5x50 screws with wall plugs

To fit this shelf you will need

A Phillips screwdriver (preferably a PZ2 tip)
A small spirit level
An SDS or hammer drill with an 8mm masonry bit

Fitting procedure

1. Screw parts A and A1 together with two of the 4x40 screws provided, this will become "assembly A".
2. Hold "assembly A" in position on the wall and mark the two mounting hole positions. Level the shelf with a spirit level on the upper flat shelf surface of A1.
3. Remove "assembly A" from the wall to drill the holes and fit the provided wall plugs.
4. Screw "assembly A" to the wall with two of the 5x50 screws provided.
5. Temporarily align part B with part A so that you can mark the position of the mounting holes on the wall. Then remove it to drill the holes and fit the wall plugs as before.
6. Screw part B into place permanently with the two 4x40 screws into part A and two 5x50 screws into the wall plugs.
7. Repeat steps 5 and 6 for part B1.
8. Screw part B1 in place permanently with two 4x40 screws through part B and one 5x50 screw into the wall plug.