

To fit this shelf you will need...

A small spirit level

A Phillips screwdriver (preferably a PZ2 tip)

An SDS or hammer drill with 8 and 14mm masonry bits

Fitting Procedure

1. Begin by drawing a horizontal line on the wall using a spirit level, make sure the line is at least as wide as the outermost fixing positions on your shelf but no wider than the shelf edges so it won't be visible after fitting.
2. If you have more than two fixing points, insert only the outermost fixings into the back of the shelf for now.
3. Hold the shelf up to the line that you have just drawn and mark the main bracket post fixing positions along this line.
4. Drill holes in the positions that you have just marked with a 14mm masonry bit. Tip: take care to drill this hole at 90 degrees to the wall as any inaccuracies could cause issues with the fitting.
5. Insert the brackets into these holes so that you can mark the retaining screw positions.
6. Once marked remove the bracket and drill an 8mm hole for each of the retaining screws. Insert the wall plugs and screw the fixings in place.
7. If your shelf has more than two fixings then you can now install the central ones. Insert the central fixings into the back of the shelf and slide the shelf half way on to the fixings that you have already fitted to the wall.
8. Pull out the central fixings until they are touching the wall to mark their positions, the outer fixings should hold the shelf in position whilst you do this. Mark their fixing hole positions as before.
9. Remove the shelf and repeat steps 4 to 6 for the central fixings.
10. The shelf is now ready to install permanently. Slide the shelf onto all of the fixings and push it flush with the wall.

Adjustments

1. The shelf strength is reliant on the fitting of the main barrel into the wall and not the retaining screws. If this needs to be adjusted at all then we recommend drilling this oversized and using a chemical resin to set the bar solidly in the wall.

